


Oppo BDP-83

Operation Manual

- Blu-ray zones A, B, C
- DVD regions 1, 2, 3, 4, 5, 6



Blu-ray zones



DVD regions

Switching zone/region is operated by the remote control.

- Turn the player off with the remote control, using the power button.
- Press and hold the blue button until the player beeps (approx 5 sec)
- Now you can select your zone:
 - Zone A & region 1: Press 1 on the remote control
 - Zone B & region 2: Press 2 on the remote control
 - Zone C & region 3: Press 3 on the remote control
 - Region 4: Press 4 on the remote control
 - Region 5: Press 5 on the remote control
 - Region 6: Press 6 on the remote control
 - Region 0 (DVD automatic): Press 0 on the remote control



Region 0, switching for standard DVDs is done automatically. Only for RCE discs manual switching might be necessary.